PART No	DESCRIPTION	QTY
GRA - 41	HUB RETAINING WASHER	1
GRA - 61	PLUG - SELECTOR HOUSING	3
GRA - 63	DRAIN PLUG	2
GRA - 68	BEARING - INPUT SHAFT	1
GRA - 69	BEARING - POCKET	1
GRA - 70	BEARING - MAIN SHAFT	1
GRA - 71	BEARING - LAYSHAFT	2
GRA - 107	WIRE CIRCLIP	4
GRA N6 005	COVER - REAR CASE	1
GRA N6 010	INER RACE - LAYSHAFT	1
GRA N6 011	REVERSE GEAR - LAYSHAFT	1
GRA N6 012	RETAINING WASHER- LAYSHAFT	1
GRA N6 018	REVERSE GEAR - MAINSHAFT	1
GRA N6 021	MAINSHAFT NUT	1
GRA N6 026	REVERSE LEVER	1
GRA N6 027	REVERSE LEVER PIVOT	1
GRA N6 028	REV. LEVER PIVOT THRUST WASHER	1
GRA N6 029	REV. LEVER WASHER	1
GRA N6 036	SLEEVE DETENT BALL ,SHORT	1
GRA N6 037	SLEEVE DETENT BALL , LONG	2
GRA N6 038	SPRING PLATE	2
GRA N6 060	SPRING PLATE TOP	1
GRA N6 080	SPRING (SHORT)	2
GRA N6 084	SPRING - NEUTRAL PLUNGER	1
H6S 031	NUT - LAYSHAFT	1
HS6 040	BOLT - LAYSHAFT	1
HKS 007	GASKET	1
HKS 008	GASKET	1
HKS 028	SPRING PLATE	1
Z 082	SPRING	1
H6S SEQ 014	DETENT PLUNGER	1
H6S SEQ 022	BRUSH	1
H6S SEQ 024	SPACER - CAM BEARING	1
H6S SEQ 027	SPRING - DETENT PLUNGER	1
J6S 112	8 POLE SWITCH	1
HML 071	ELECTRONIC GEAR IND.SYSTEM	1

PART No	DESCRIPTION	QTY
GTR SEQ-001	MAIN CASE	1
GTR SEQ-002	BELL HOUSING	1
GTR SEQ-003	CAM SHAFT OVERDRIVE 6th	1
GTR SEQ-004	SELECTOR ROD 3RD / 4TH	1
GTR SEQ-005	SELECTOR ROD 1st / 2nd	1
GTR SEQ-006	SELECTOR ROD 5th / 6th	1
GTR SEQ-007	SELECTOR ROD REV	1
GTR SEQ-008	SPIRAL ACTUATOR	1
GTR SEQ-009	GEAR LEVER - ROD	1
GTR SEQ-010	INTERMEDIATE ROD	1
GTR SEQ-011	PAWL CARRIER	1
GTR SEQ-012	NEUTRAL ACTUATOR	1
GTR SEQ-013	GUIDE - INTERMEDIATE ROD	1
GTR SEQ-014	GUIDE - REV. SELECTOR ROD	1
GTR SEQ-015	GUIDE SPIGOT	1
GTR SEQ-016	CAP - GUIDE SPIGOT	1
GTR SEQ-017	WASHER CENTRALISER	1
GTR SEQ-018	SPACER CENTRALISER	1
GTR SEQ-019	CAM FOLLOWER - REVERSE	1
GTR SEQ-020	CAM FOLLER 3rd / 4th	1
GTR SEQ-021	PAWL	2
GTR SEQ-022	STOP PLATE	1
GTR SEQ-023	STOP WASHER PAWL	1
GTR SEQ-024	NEUTRAL LATCH	1
GTR SEQ-025	STRIKER - NEUTRAL LATCH	1
GTR SEQ-026	ROD - NEUTRAL LATCH	1
GTR SEQ-027	WASHER - NEUTRAL LATCH	1
GTR SEQ-028	CAM SHAFT 1:1 TOP	1
GTR SEQ-029	ROD CONNECTOR	1
GTR SEQ-030	FORK 1st - 2nd	1
GTR SEQ-031	FORK 3rd - 4th	1
GTR SEQ-032	FORK 5TH - 6TH	1
GTR SEQ-033	ROD END - REVERSE	1
GTR SEQ-034	SPACER NEEDLE BEARING	3
GTR SEQ-035	REVERSE IDLER	1
GTR SEQ-036	SPINDLE - REVERSE IDLER	1

PART No	DESCRIPTION	QTY
GTR SEQ-037	COVER - SPIRAL ACTUATOR	1
GTR SEQ-038	SANDWICH PLATE	1
GTR SEQ-039	REAR CASE	1
GTR SEQ-040	HUB 5TH / 6TH	1
GTR SEQ-041	HUB 3rd / 4th	1
GTR SEQ-042	HUB 1st / 2nd	1
GTR SEQ-043	DOG GEAR 3rd / 4th / 6th	3
GTR SEQ-044	DOG GEAR 1st / 2nd	2
GTR SEQ-045	INPUT SHAFT	1
GTR SEQ-046	LAY SHAFT	1
GTR SEQ-047	SPACER-LAYSHAFT CM-6th	1
GTR SEQ-048	SPACER-LAYSHAFT 1st-2nd	1
GTR SEQ-049	MAIN SHAFT	1
GTR SEQ-050	BEARING SLEEVE - 4th GEAR	1
GTR SEQ-051	BEARING SLEEVE 1st GEAR	1
GTR SEQ-052	BEARING SLEEVE - 2nd GEAR	1
GTR SEQ-053	SPLINED GEAR C.M.	1
GTR SEQ-054	SPLINED GEAR - 6th	1
GTR SEQ-055	SPLINED GEAR - 3rd	1
GTR SEQ-056	SPLINED GEAR 4th	1
GTR SEQ-057	SPLINED GEAR - 1st	1
GTR SEQ-058	SPLINED GEAR - 2nd	1
GTR SEQ-059	SPRING-GEARLEVER RETURN	2
GTR SEQ-060	PLUNGER-NEUTRAL/REVERSE	1
GTR SEQ-061	PLUNGER - FIXED	1
GTR SEQ-062	SPRING	1
GTR SEQ-063	SLEEVE-CLUTCH THROWOUT	1
GTR SEQ-064	CROSS PIN-SPIRAL ACTUATOR	1
GTR SEQ-065	ROLLER - SPIRAL ACTUATOR	2
GTR SEQ-066	WASHER - SPIRAL ACTUATOR	2
GTR SEQ-067	COVER-H PATT. REV. PLUNGER	1
GTR SEQ-068	SPRING - NEUTRAL LATCH	1
GTR SEQ-069	SPRING - PAWL	2
GTR SEQ-070	SPACER-BEARING INPUT SHAFT	1
GTR SEQ-071	SPACER-BEARING LAY SHAFT	1
GTR SEQ-072	SELECTOR RING	3

















PART No	DESCRIPTION	QTY
000 0620	M6 X 20 HEX HEAD BOLT	8
000 0830	M8 X 30 HEX HEAD BOLT	6
001 0512	M5 X 12 CAP SCREW	13
001 0516	M5 X 16 CAP SCREWS	2
001 0612	M6 X 12 CAP SCREWS	3
001 0830	M8 X 30 CAP SCREWS	3
001 0835	M8 X 35 CAP SCREWS	1
002 0512	M5 X 12 C/S CAP SCREWS	4
006 0839	M8 X 39 STUD	2
006 0870	M8 X 70 STUD	6
006 0873	M8 X 73 STUD	4
006 08159	M8 X 159 STUD	1
006 1257	M12 X 57 STUD	4
01206037	3/8 UNC X 0.375 GRUB SCREW	3
0208	M8 PLAIN NUT	13
020 12	M12 PLAIN NUT	4
023 08	M8 NYLOC NUT	1
031 05	5mm WAVE WASHER	2
031 06	6mm WAVE WASHER	8
031 08	8mm WAVE WASHER	19
031 12	12mm WAVE WASHER	4
035 08	3/4 B.S.P. DOWTY WASHER	2
040 0820	M8 X 20 DOWEL	2
040 0825	M8 X 25 DOWEL	2
040 0850	M8 X 50 DOWEL	2
041 0206	M2 X 6 ROLL PIN	1
041 0310	M3 X 10 ROLL PIN	1
041 0416	M4 X 16 ROLL PIN	2
041 0522	M5 X 22 ROLL PIN	10
041 0509	M5 X 9 ROLLPIN	2



PART No	DESCRIPTION	QTY
101 0516	5/16 BALL	3
103 153209	6002 BALL BEARING	1
103 173510	6003 BALL BEARING	1
103 103009	6200 BALL BEARING	1
106 162013	K16 X 20 X 13 NEEDLE CAGE	1
106 162017	K16 X 20 X 17 NEEDLE CAGE	1
106 424727	K42 X 47 X 27 NEEDLE CAGE	5
108 425220	NK 42/20 NEEDLE ROLLER BEAR.	2
120 1815	MB1815DU BUSH	1
120 1820	MB1820DU BUSH	1
121 0908	08DU08 BUSH	10
121 0912	09DU12 BUSH	2
130 354707	35 X 47 X 7 SEAL	1
140 20	INA BR 20 CIRCLIP	2
140 52	INA BR 52 CIRCLIP	4
145 04	D1500 0040 E CLIP	2
144 0716	7/16 CIRCLIP	1

Holinger Eng. Co.	20 Railway Cr.,CROYDON 3136
Part No	GTR SEQ ASSEMBLEY
Name	ASSEMBLY - GEARBOX OVER DRIVE 6th
Matl.	PARTS AS SHOWN
Dr. J.P.H.	Date 1-5-99
Scale	